

espresso

and coffee solutions

Telephone: 03 5248 8855 Email: sales@espressocoffeesolutions.com.au
 Postal address: PO Box 1066 Geelong Victoria Australia 3220
 Showroom: 310 Boundary Road East Geelong Victoria
 Internet: www.espressocoffeesolutions.com.au

FACT SHEET Twice daily maintenance - Cleaning the milk system



IMPRESSA X9

TWICE DAILY MAINTENANCE

Cleaning the milk system. (auto frother)

No matter what type of machine you have, milk scum will affect the performance of your machine and is a health hazard. Old milk sticks in the corners and walls of milk frothers and is hard to reach lines and heating components. Clean Machine Milk Steamer solution cleans and sanitises all the milk system components. We recommend to clean the milk system daily.

You will need:

1. 2 containers to hold approximately 500 mls of water
2. Clean Machine Milk steamer solution

PLEASE NOTE:

- Do not interrupt program once started.
- This program lasts approximately 2 minutes
- Always dip both hoses into the fluid.

Open the programming door on the front. Press the Clean Milk System key (Fig. 1) until you hear an acoustic signal.



CLEAN CAPPU

START
YES

DURATION
APPROX 2'



To initiate milk cleaning, press either the P button or the Milk Cleaning button. (Fig. 1)

CLEANER FOR CAPPUCINO

Place a receptacle with a capacity of at least 0.5 litres under the height-adjustable dual spout. Fill one container with 1/2 a litre of hot water and add 25mls of Clean Machine Milk Steamer Solution. Dip the two milk hoses into this solution. Press the Clean Milk System key (Fig. 1).

PRESS
KEY

MACHINE CLEANING

You will hear an acoustic signal.

WATER FOR CAPPUCINO



Fill a receptacle with approx. 500mls of fresh water and dip the milk hoses into it. Press the Clean Milk System key (Fig. 1).

PRESS
KEY

MACHINE CLEANING

COFFEE READY

Wipe down the coffee machine with a wet cloth to remove all milk and coffee residue.

THE CLEANING PROGRAM IS NOW COMPLETE.

Weekly Maintenance of auto frother.

At the end of each week remove hoses and auto frother and soak in Clean Machine Milk Steamer Solution for 30 min. Rinse and re-assemble.

espresso

and coffee solutions

Telephone: 03 5248 8855 Email: sales@espressocoffeesolutions.com.au
 Postal address: PO Box 1066 Geelong Victoria Australia 3220
 Showroom: 310 Boundary Road East Geelong Victoria
 Internet: www.espressocoffeesolutions.com.au

FACT SHEET #1 Weekly maintenance - Cleaning the coffee system



IMPRESSA X9

WEEKLY MAINTENANCE

Cleaning the coffee system.

Some automatic machines have a brewing chamber that is difficult to access. Tablets aid in removing coffee build up from within the brewing chamber of these machines. We recommend to clean the coffee system weekly.

PLEASE NOTE:

- Do not interrupt program once started.
- This program lasts approximately 20 minutes.

You will need:

1. 1 large container 500mls
2. Clean Machine Coffee Cleaning Tablet x 1.

Open the programming door (Fig. 4) and press the Clean Coffee System key (Fig. 1) until you hear an acoustic signal.



(Fig. 1)

CLEAN COFFEE

START
YES

DURATION
APPROX 20'

To initiate coffee cleaning, press either the P button or the Coffee Cleaning button (Fig. 1).

EMPTY

TRAY

EMPTY

COFFEE BIN

Remove the tray and the grounds bin and EMPTY the coffee grounds.

COFFEE BIN

MISSING

Place the grounds bin and the tray back into the machine.

PRESS
KEY

Place a sufficiently large receptacle under the height-adjustable dual spout (Fig. 6).

MACHINE CLEANING

Press the Clean Coffee System key (Fig. 1) until you hear an acoustic signal.

You will hear an acoustic signal. Drop a Clean Machine coffee cleaning tablet into the decaf shoot / funnel.

ADD TABLET

PRESS
KEY



Press the Clean Coffee System key (Fig. 1).

MACHINE CLEANING

(approx.15 min)

You will hear an acoustic signal.

EMPTY

TRAY

EMPTY

COFFEE BIN

Remove the tray and the grounds bin and EMPTY the coffee grounds.

COFFEE BIN

MISSING

Place the grounds bin and the tray back into the machine.

COFFEE READY

THE CLEANING PROGRAM IS NOW COMPLETE.

espresso

and coffee solutions

Telephone: 03 5248 8855 Email: sales@espressocoffeesolutions.com.au
 Postal address: PO Box 1066 Geelong Victoria Australia 3220
 Showroom: 310 Boundary Road East Geelong Victoria
 Internet: www.espressocoffeesolutions.com.au

FACT SHEET Monthly maintenance - Descaling



IMPRESSA X9

MONTHLY MAINTENANCE

Descaling.

Scale is formed by minerals such as calcium, lime & magnesium. The heating and cooling of water causes these minerals to harden and form a white layer or crust on the internal surfaces of your coffee machine. There are 2 reasons to descale your machine. Over time scale builds up making it difficult for the machine to reach optimum operating temperature which in turn reduces the quality of your coffee. To correct extract coffee oils for the best tasting coffee there is a small but critical temperature window. Brewing outside of this range will result in unpleasant tasting coffee. Secondly, is to prevent small pieces of scale detaching and blocking the machine flow paths. Scale contributes to over 50% of machine breakdowns and component failure. We recommend descaling your machine monthly.


PLEASE NOTE:

- Do not interrupt program once started.
- This program lasts approximately 45 minutes.


You will need:

1. 1 litre container
2. Clean Machine Triple Action descaling formula.

Open the programming door on the front and press the Decalcify key (Fig. 3).



(Fig. 3)



To initiate descaling, press either the P button or the De-Scale button (Fig. 3).

EMPTY TRAY

EMPTY COFFEE BIN

Remove the tray and the grounds bin and EMPTY the coffee grounds.

COFFEE BIN

MISSING

Place the grounds bin and the tray back into the machine. Remove the water tank and empty it. Pour 500mls of water mixed with 50mls of Clean Machine Triple Action Formula into the empty water tank.

SOLVENT IN TANK

Place 3 sufficiently large receptacles under the height adjustable dual spout, the steam spout and the hot water spout. Press the Decalcify key (Fig. 3).

PRESS KEY

MACHINE DECALCIFYING (takes approx. 40 min.)

You will hear an acoustic signal.

EMPTY TRAY

Remove the tray and the grounds bin. EMPTY the coffee grounds.

TRAY

MISSING

Place the grounds bin and the tray back into the machine.

WATER TANK

RINSE / F

Thoroughly rinse out the water tank and fill it with fresh tap water. Place the water tank back into the machine. Place 3 sufficiently large receptacles under the height adjustable dual spout, the steam spout and the hot water spout (Fig. 18, 1/2 litre receptacle each).

PRESS KEY

Press the Decalcify key (Fig. 3).

MACHINE DECALCIFYING

CAPPUCCINO

RINSING

You will hear an acoustic signal.

EMPTY TRAY